9.7 TM ASSY-S


12
1
SRVB
CN7004
Lubricating oil
(GYA1001)
10
5
Cleaning liquid (GEM1004)
Cleaning paper (GED-008)
3
8
9
7
4
6
SPCN
CN6102
2
8
4
11
11
13

TM ASSY-S SECTION PARTS LIST

Mark	No.	Description	Part No.
NSP	1	Stepping Motor SK	DXM1227
NSP	2	Spindle Motor G11(N)	DXM1231
NSP	3	09SD Pickup Assy	OWY8177
NSP	4	Adjust Screw	DBA1263
NSP	5	Skew Spring	DBH1437
NSP	6	Joint Spring (J)	DBK1261
NSP	7	Slider Spring G11 (J)	DBK1262
NSP	8	Guide Shaft (S)	DLA1918
	9	Joint	DNK3858
NSP	10	Mounting Plate G11(J)	DNK4307
	11	Tapping Screw 04	VBA1092
	12	Screw	BPZ20P080FTC
	13	Screw	BPZ26P080FTC